



(e) 1/2" fiberboard

(e) framing (2x4 @ 16" o.c.)

(n) blown-in cellulose

(n) 1" xps foam air barrier, taped seams, minimize penetrations

(n) 2x3 framing, stagger w. existing wall studs, stand off xps by 1"

(n) mineral wool batts, ensure coverage behind 2x3 studs

(n) gypsum board wall finish

