

<== South

Plane of rough-cut 1x8 hemlock @ 45deg.

1/2" Homasote fiberboard

60mil fully-adhered EPDM

These last three cavities are empty.

2 X 6 (12" ctrs.)

2 X 6 both sides, glued & screwed

Vertical battens on TJI's for rain plane

DP cellulose throughout TJI plane

16" TJI (3' ctrs.)

DP cellulose throughout TJI plane

Webs glued & screwed

Horizontal battens control pillowing

6 X 10 Rafter (3' ctrs.)

2 X 8 T&G pine

16" TJI (3' ctrs.)

8 X 8 POST

Intello

Vertical 3/4" cedar T&G sheathing

Solitex Mento 1000

North ==>

2" off-frame hemlock spacer  
3/4" cedar T&G interior sheathing

Whitchurch Cottage elevation of wall-to-roof detail E. view 130411

Note: DP webbing atop roof TJI's & 2x6's, Cor-A-Vent, all fasteners, etc., are implied.

Note: inner flanges of TJI's are cut away before they leave the bldg.