



11. Install backer rod and sealant around the interior perimeter of the window to complete air barrier continuity.



12. Install sheathing tape along the jambs of the window frame and extend to the face of the wall.



13. Install metal flashing at the head of the window. Seal the leading edge of the flashing with sheathing tape.



14. Install sheathing membrane. Ensure positive laps over all other layers. Seal the leading edge with sheathing tape.



15. Install ROXUL® COMFORTBOARD™ 80 and secure with strapping. Provide bugscreens at the top and bottom of the strapping.



16. Install prefinished metal sill flashing. Attach the sill flashing to the nailing flange under the window sill.