



INITIALLY I WAS GOING TO FILL THE ENTIRE AREA BETWEEN THE ROOF RAFTERS WITH THE RIGID FOAM, BUT THAT WOULD HAVE BEEN A LOT OF INSULATION.

I AM WONDERING IF I CAN FILL THE VOID WITH CELLULOSE OR SHOULD I JUST FILL THE WHOLE THING W/ RIGID???

THE WHOLE POINT OF THIS IS TO ENSURE THAT THE WALKING SURFACE IS SUPPORTED ON THE "RAFTERS" AND NOT ON RIGID FOAM LAID ON THE ROOF DECK. AM I WRONG IN NOT WANTING THE WALKING SURFACE ON THE INSULATION?