

FROM ABOVE CURRENT

STEP 1 - 3" Poly

+ 1 part Spray Foam  
(can)

OUTSIDE

