

# BRICK WINDOW BUCK INSTALL

- INSTALL 1X4 WINDOW BUCK AROUND WINDOW OPENING BEFORE INSTALLING FLEXWRAP PAN AND WINDOW

