

	Great Room And Nook	Kids' Rooms	Below Roof-Top Deck	Vented Attic
<b>Nominal Framing:</b>	8" unvented ceiling	6" unvented ceiling	10" unvented ceiling	6" or 8" attic floor
<b>Current Insulation:</b>	fiberglass batt	4.5" Polyiso	fiberglass batt	4.5" polyiso or ~8" batt
<b>Roof Sheathing:</b>	Radiant Barrier OSB	Radiant Barrier OSB	Radiant Barrier OSB	Radiant Barrier OSB
<b>Approx R-Value:</b>	R-27	R-30	R-30	~R-36 (if more vents added)
<b>Key issues:</b>	<ul style="list-style-type: none"> <li>- Rigid insulation required above batt per R806.5</li> <li>- Potential moisture trapping from OSB radiant barrier</li> </ul>	<ul style="list-style-type: none"> <li>- upper/lower foil on polyiso</li> <li>- Potential moisture trapping from OSB radiant barrier</li> </ul>	<ul style="list-style-type: none"> <li>- Rigid insulation required above batt per R806.5</li> </ul>	<ul style="list-style-type: none"> <li>- Upper/lower foil on Polyiso in attic floor</li> </ul>

<b>Budget Mod:</b> <b>(ventilate)</b>	<ul style="list-style-type: none"> <li>- Install vent ridges</li> <li>- Cut vent holes in blocking at mid-rafter</li> </ul>	<ul style="list-style-type: none"> <li>- Remove drywall</li> <li>- Remove polyiso</li> <li>- Install vent ridges</li> <li>- Cut vent holes in blocking at mid-rafter</li> <li>- Add batt in 5.5-in cavity</li> <li>- Add drywall</li> </ul>	<ul style="list-style-type: none"> <li>- Remove drywall</li> <li>- Remove batt</li> <li>- Spray PU insulation</li> <li>- Add batt</li> <li>- Add drywall</li> </ul>	<ul style="list-style-type: none"> <li>- Remove polyiso inside attic floor</li> <li>- Replace with batt</li> </ul>
<b>Post-Mod R:</b>	R-27	R-22	same	same

<b>Major Mod:</b> <b>(new roof)</b>	<ul style="list-style-type: none"> <li>- Remove roof down to insulation layer</li> <li>- Add new OSB, 1.5" polyiso, OSB, underlayment, and shingles</li> </ul>	<ul style="list-style-type: none"> <li>- Remove roof down to insulation layer</li> <li>- Add new OSB, 1.5" polyiso, OSB, underlayment, and shingles</li> </ul>	Same as above	Same as above or: <b>Convert to unvented attic &amp; Keep polyiso in floor</b> <ul style="list-style-type: none"> <li>- Remove shingles, underlay, OSB</li> <li>- Add new OSB, 1.5" polyiso, OSB, underlay., and shingles</li> </ul>
<b>Post-Mod R:</b>	R-30	R-30	same	tbd
<b>Compared to minor-mod:</b>	<ul style="list-style-type: none"> <li>- R806.5 code compliant</li> <li>- Meets R-30 in T24 Cert.</li> </ul>	<ul style="list-style-type: none"> <li>- R806.5 code compliant</li> <li>- Meets R-30 in T24 Cert.</li> <li>- Bedrooms undisturbed</li> </ul>	same	<ul style="list-style-type: none"> <li>- 806.5.2 violation (vapor retarder on polyiso) - but dT same on both sides so maybe OK</li> <li>- polyiso removal avoided</li> </ul>